


FmX / EZ-Boom / EZ-Steer / ~~RTK corrections~~ / power bus

This figure shows how to connect the FmX integrated display with the EZ-Steer and EZ-Boom systems ~~while using RTK corrections:~~



Item	Description	Trimble part number
①	FmX integrated display	93100-02
②	FmX power cable	66694
③	FmX power cable with relay and switch (power bus)	67259
④	FmX basic power cable	67258
⑤	8 m GPS TNC/TNC RT angle cable	50449
⑥	Ag25 GNSS antenna	68040-005
⑦	NMO to TNC 20ft antenna cable and base	62120
⑧	900 MHz radio antenna kit	22882-10
⑨	FmX to CAN cable with port replicator	75407
⑩	EZ-Boom 2010 to FmX display and EZ-Guide 500 cable	61437
⑪	CAN terminator	59783
⑫	EZ-Boom controller	59898-00
⑬	FmX to EZ-Steer cable	75742
⑭	EZ-Steer controller	53348-10

Item	Description	Trimble part number
⑤	EZ-Steer motor cable	62257
⑥	EZ-Steer motor	53058-00

Note – The EZ-Steer assisted steering system must be powered separately to power the motor.

Note – To use the EZ-Guide 500 lightbar cable (P/N 62974) and instructions on how to repin the cable, see the support bulletin AgGPS FmX - Modifying EZ-Steer Cable P/N 62974 For Use With FmX.